
Installation Instruction for Belluna RV Entry Door

Steps:

1. Make a hole to install a door

Make a cut-out hole according to the door ordering size. For our standard door 620*1800mm, you need to make a hole 620*1800mm with two upper rounded corner R 90 (refer to the below drawing). (Different size -> different cut hole size)

Remark: Red color is the external overall size of the door; white color is for the cut-out size.



2. Apply the waterproof glue to the four edges of the door frame



3. Put the door into the hole you have made and make sure the door has completely been embedded in the caravan body (During this process, the glue will be squeezed out between the wall and door frame. Please remove it when the glue dries enough after two to three days after the installation).



4. Use electric drill make holes to the in side door frame (four surface) (Each surface make two holes).



5. Mount the screws into the holes (as the picture show).



Application

